



GLIDESKINNE FOR SCREENIT A30 SLIDE

ARTIKLER

ART.NR	STÖRRELSE/BESKRIVELSE	Farge	B	H:	D:
668140-1	Glideskinne for ScreenIT A30 Slide	hvit	1400	77	27
668140-3	Glideskinne for ScreenIT A30 Slide	sølv	1400	77	27
668160-1	Glideskinne for ScreenIT A30 Slide	hvit	1600	77	27
668160-3	Glideskinne for ScreenIT A30 Slide	sølv	1600	77	27
668180-1	Glideskinne for ScreenIT A30 Slide	hvit	1800	77	27
668180-3	Glideskinne for ScreenIT A30 Slide	sølv	1800	77	27
668200-1	Glideskinne for ScreenIT A30 Slide	hvit	2000	77	27
668200-3	Glideskinne for ScreenIT A30 Slide	sølv	2000	77	27